## For Style 1112P32-12 Assembly Instruction Sheet #S-1112P32-12

source: (12) E12 Candelona Base Bube 60W Maximum (Not Include).

\*\*Base Time: 20-30 minutes\*\*


\*\*Blance Maximum (Not Include).

ed Assembly Time: 20-30 minutes Morr: Identify and impact all puris before beginning installation. Check package content let and diagrams below to be sure all parts Jent. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fidure. Contact customer service for

TRACLILE LEICHEC

These instructions are provided for your safety, it is very important you read them completely before installing the foture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect that re from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool ⚠ Warnings and Cautions
Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.



Hardware Contents Canopy Chain Loop Outlet Box Screw Canopy Lock Ring DESCRIPTION 8 **= 0**\*= 8 3pgs H Dos

# 88 #

₹

PART ⋛

> D. Use the screw to fix the (D) Nibble one end with the cross rod on Fxiture Body A and the other end lock with C.Fix the other end of (F )Nibble with the coupling on the A.Fix the (F) Nibble with the Loop on the Fixture Body (A) pull the electricity wire from the (F) Nibble. STEP 1 -Assemble the Fixture Body Fixture BodyB, tighten them together. Connect the wires together (Pay attention to the wire negative with negative positive with positive ). B.Loose the Lamp Box on the (B) Fixture BodyB , pull the **extricity wire which come from (F) Nibble.**

the coupling of Fbdure Body B. cross rod on Fixture Body A and the other end lock with E.Use the screw to lock one end of Nibble E with the

the (C) Crystal Holder. (A) Fixture Body (F) Nibble (+) ectricity wire (C) Crystal Holder (E) Nibble P Chy Lock Screw Refer to Wire (D) Nibble (B)Fb:ture BodyB Lock Screw

F. Raise the ceiling canopy

another quick link. The fixture will now hang sa

over the canopy
chain loop. Tighten
the canopy lock
ring onto the canopy chain

oop until tight

the foture chain and

SupplyDDWIres and

8

ocx mg up

and camply

A.Thread the ripple into the crossber . Thread the book washer and the hex nut onto top end of the hipple. Do not tighten at this moment STEP 2 - Install the Canopy Chain Loop and Nipple

A. Use standard wire connectors (not included) to make all wire

connections. Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box.

STEP 4 - Wire Connections

B. Attach the grossbar to the outlet box and escure with outlet box ecrews (not included). Hand tighten until erug.


G.Thread the campy chain loop onto the end of the ripple and hand tighten until artup. Place the calling campy over the campy drain loop against the calling to determine the campor position of therappte.

Thread the campy look ring onto the campy chain loop. Adjust the nipple to allow the calling campy to rest against the calling when hipple to allow the calling campy to rest against the calling when held in place by the canopy lock ring

White wire from outlet box

White wire from fixture

from fixture Black wire




Calling Canopy Canopy Lock Ring Black wire from outlet box (or Red)

Bare, or Green Ground wire from outlet box Bare, or Green Ground wire from outlet box Figure 4 on the Crossbar Green Ground Screw Ground wire from fodure from fixture Ground wire

STEP 3 - Install the Fixture Chain and Ceiling Canopy

A Install bubs onto sockets and push snug into place

A Adjust the fixture chain to your desired length by removing links B. Please put the crystal to the Fixture Body (A).



Figure

Connection A

Figure 3