

## INSTRUCTIONS FOR CONCEPT LED CORDLESS PICTURE LIGHT

### INSTALLATION (Picture Frame):

1. Loosen thumbscrew and detach the light from the base.
2. Mark a vertical line in the center of the frame. (on the back)
3. Install the base to the frame using the screws provided.  
(Use a minimum of 2 screws)
4. Replace picture; slide the light into the base and tighten thumbscrew

### INSTALLATION (Wall):

1. Loosen thumbscrew and detach the light from the base.
2. Mark the wall (with a dot) at the center line of frame- level with the top of the frame.
3. After removing picture from the wall, draw a vertical line downwards from the dot.
4. Install the base to the wall using the screws and anchors provided. (using all 3 screw/anchors) is recommend, but use no less than 2.
5. Replace picture; slide the light into into the base and tighten thumbscrew

### BATTERY REPLACEMENT:

1. Detach the light from the base
2. Turn light upside down
3. Using thumb, slide battery door towards oneself and remove.
4. Insert batteries

### OPERATION:

From manual switch on lamp:

Press once for ON/OFF

When on, press and hold button to cycle through the 4 dimming settings

From remote control:

Use the ON/OFF button on the left side to turn on and off.

Use up and down buttons on right side for dimming