

2410-150 5 DRAWER CHEST

Assembly Instruction

A . Components :

1, Five Drawer Chest


Qty
1 x



a



b



c



d



e

B . Hardware :

Qty


a. Screw Ø8 x 2" 1 x

b. Screw Ø8 x 5/8" 1 x

c. Restrain Strap 1 x

d. Metal Plate 2 x

e. Plastic Anchor 1 x



WARNING

Serious or fatal crushing injuries can occur from furniture tipover. To help prevent tipover:

- Install tipover restraint provided.
- Place heaviest items in the lowest drawers.
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- (OR)
- Do not defeat or remove the drawer interlock system

Use of tipover restraints may only reduce, but not eliminate, the risk of tipover.
This is a permanent label. Do not remove!