

# 2410-430 NIGHTSTAND

## Assembly Instruction

A . Components :  
1, Nightstand

Qty  
1 x




a



d



b



c




e

B . Hardware :

Qty

- |                    |     |
|--------------------|-----|
| a. Screw Ø8 x 2"   | 1 x |
| b. Screw Ø8 x 5/8" | 1 x |
| c. Restrain Strap  | 1 x |
| d. Metal Plate     | 2 x |
| e. Plastic Anchor  | 1 x |



**WARNING**

Serious or fatal crushing injuries can occur from furniture tipover. To help prevent tipover:

- Install tipover restraint provided.
- Place heaviest items in the lowest drawers.
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- (OR)
- Do not defeat or remove the drawer interlock system

Use of tipover restraints may only reduce, but not eliminate, the risk of tipover.  
*This is a permanent label. Do not remove!*