

# Slim-Line Picture Light Installation

## I. PREPARE THE LIGHT

1. Unpack the light and rotate arms so they are perpendicular to the shade (FIG 1)
2. Install bulbs (see bulb replacement instructions below).
3. Start the Thumb Screws (d) in the center tab of the T Brackets so the end of the screw is flush with the inside of the threaded hole (FIG 2)

## II. MOUNT THE T BRACKETS

### A. TO A FRAME

1. On the back side of the frame, mark the center of the top edge.
2. Similarly, mark locations for the outer edge of the T Brackets using the dimensions in the table to the right.
3. For a wood frame, align the T brackets with the top of the frame and attach them using screws "a" through the larger holes in the T Bracket.
4. For a metal frame:
  - a. Using pliers, fold back the side tabs on the T Brackets (FIG 3).
  - b. Start screws "b" into the smaller holes in the T Brackets.
  - c. Insert the larger side tab of the T Bracket into the frame channel on an angle, then rotate it in line with the edge of the frame (FIG 4).
  - d. Insert the smaller side tab into the frame channel and tighten screws "b" snugly.

### B. TO THE WALL

1. Determine the desired height of the picture. Using a level, mark a very light line on the wall at the top of the frame and mark the center of this line.
2. Mark the locations along that line for the outer edges of the T Brackets, referring to the chart above.
3. Hold each T Bracket in place on the wall and mark the locations of both larger mounting holes on both T Brackets.
4. Drill a 1/4" hole in the wall at the four marks you just made. Insert the anchors, then attach the T Brackets to the wall with screws "c" .

## III. INSTALL THE PICTURE LIGHT

1. Snap the arms in between the tabs of the T Bracket (FIG 5). This will take a bit of force, but it will not damage the arms.
2. Slide the arms up or down to attain the desired height of the picture light. You will most likely want the shade at about the level of the top of the frame. Tighten the setscrews to hold the light at this height.
3. You may adjust the direction of the light by loosening both Adjustment Screws (FIG 6) and rotating the shade. You may need gloves or a piece of cloth if the light is hot.
4. Attach the two plastic bumpers on the bottom corners of the frame. This will protect your wall from scratching, and also allow the frame to be offset from the wall in order to accommodate the junction box on the end of one of the arms.

## IV. BULB REPLACEMENT



1. UNPLUG THE POWER CORD.
2. Tilt each socket down with a fingernail (FIG 7).
3. Replace bulb.

### NOTES ON PICTURE LIGHT INSTALLATION:

House of Troy Picture Lights come equipped with an Ivory cord and a line switch. If you would like to conceal the cord, you may consider one of the following:

1. Paint the cord to blend in with your wall covering.
2. Use a cord cover in a brass finish or paint it to match your wall. Other options would be to cover it with wall paper or fabric.
3. A clock outlet with a remote wall switch is an ideal solution. This conceals the cord behind the frame (clock outlets also have built-in picture hangers). For added warmth, use a dimmer switch - this is the ultimate picture light installation.

Z:\Autocad Files\Parts\B&WLogo.bmp



Screws Included

Lamp Model	Center To Outer Bracket Edge
SL6	4"
SL11	6-1/4"
SL16	9"
SL21	11-1/8"
SL30	16-1/8"
SL40	21"

